

SL MEGA RIFLE REST - RANSOM SL MEGA RIFLE REST

RANSOM INTERNATIONAL SL MEGA RIFLE REST Ransom International asked some of the top FCSA (Fifty Caliber Shooters Association) and NBRSA (National Bench Rest Shooters Association) shooters: "What would you want in a rifle rest?" – Here it is. A high caliber bench rest 36 inches long, 15 inches wide, 3/8" plate steel. Approximately 90 pounds (basic Rest) Rhino coated for protection and vibration dampening. Two separate plates, the Rear, Windage Plate, and the Front, Elevation Plate, connected with a removable Bridge Plate. Some shooting disciplines allow the front and rear rests to be connected. Some don't. The Ransom Rifle Master SL Mega Rest can be used both ways. Set up at the range, then remove the Bridge Plate. That allows you to precisely align the Front and Rear Plates. Or, if the rules allow, leave it attached. Also, it makes the Mega Rest easier to carry to the firing line. The Front Plate is drilled and tapped for front to rear adjustment of the Elevation Block. Two 1/4" screws attach the Elevation Block to the Front Plate. And, the Elevation Block has a level embedded in the block allowing the Front Plate to be leveled separately from the Rear Plate. Attached to the Elevation Block is a 2" diameter Major Column. This, in turn, holds a 1.25" Minor Column threaded with 10 turn in 1 inch Acme Thread for precise adjustment using the cast iron Elevation Wheel. The Front Plate also has three 1/2"-20 hardened Base Leveling Screws with knurled Locking Rings. The Rear Plate has Ransom International's Windage Adjustable Bag Plate in their new Quick Change Plate. Remove four screws and change the Windage Adjustable Bag Plate from Right to Left hand windage adjustment. Or, change to another Bag Plate altogether. Three 1/2-20 hardened Base Leveling Screws with knurled Lock Rings. And there's a level embedded in the center of the Rear Plate.



Attributes

- Name: RANSOM SL MEGA RIFLE REST
- Manufacturer: RANSOM
- Product no.: 430119617
- Mfr. No.: RS-50-1000
- Material: Multiple
- Style: Rest
- Delivery weight: 58.967kg
- Shipping height: 457mm
- Shipping width: 305mm
- Shipping length: 457mm
- UPC: 810132583629

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SL MEGA RIFLE REST von RANSOM](#)
- [English: SL MEGA RIFLE REST Safety Instruction Guide](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per il SL MEGA RIFLE REST di RANSOM](#)

Sicherheitshinweise für die SL MEGA RIFLE REST von RANSOM

Einführung

Willkommen zu den Sicherheitshinweisen für die SL MEGA RIFLE REST von RANSOM. Dieses Produkt wurde entwickelt, um dir eine präzise Unterstützung beim Schießen zu bieten. Um sicherzustellen, dass du das Produkt sicher und effektiv nutzen kannst, befolge bitte die folgenden Richtlinien.

Allgemeine Sicherheitsrichtlinien

- Stelle sicher, dass du die SL MEGA RIFLE REST nur für den vorgesehenen Zweck verwendest.
- Überprüfe das Produkt regelmäßig auf Beschädigungen oder Abnutzung.
- Bewahre das Produkt außerhalb der Reichweite von Kindern auf.
- Verwende das Produkt nur in einem sicheren und geeigneten Umfeld.
- Halte dich an alle geltenden Gesetze und Vorschriften für das Schießen in deiner Region.
- Informiere dich über die Notfallkontakte in deiner Nähe für den Fall eines Unfalls.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwende die SL MEGA RIFLE REST nur mit Gewehren, die für die Verwendung mit einem Gewehrständer geeignet sind.
- Achte darauf, dass die Bankstütze stabil auf einer ebenen Fläche steht, bevor du sie verwendest.
- Stelle sicher, dass alle Schrauben und Verbindungen fest angezogen sind, bevor du das Produkt in Gebrauch nimmst.
- Vermeide es, die SL MEGA RIFLE REST während des Schießens zu bewegen oder zu verstellen.
- Verwende beim Schießen immer geeignete Schutzausrüstung, wie Gehörschutz und Schutzbrille.

Anweisungen zur Installation und Nutzung

1. Vorbereitung

- Überprüfe alle Teile der SL MEGA RIFLE REST auf Vollständigkeit und Unversehrtheit.
- Stelle sicher, dass der Standort für die Benutzung geeignet ist.

2. Installation

- Stelle die SL MEGA RIFLE REST auf eine stabile, ebene Fläche.
- Verbinde die Hintere WindagePlatte und die Vordere ElevationPlatte, wenn erforderlich.
- Ziehe alle Schrauben und Verbindungen fest.

3. Nutzung

- Setze dein Gewehr auf die SL MEGA RIFLE REST und stelle sicher, dass es stabil sitzt.
- Nimm die erforderlichen Anpassungen an der Vorderplatte und der Hinterplatte vor, um eine präzise Ausrichtung zu gewährleisten.
- Achte darauf, dass du die Windage Adjustable Bag Plate korrekt einstellst.

Entsorgungsanweisungen

- Entsorge das Produkt gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Überprüfe, ob Teile des Produkts recycelbar sind, und trenne sie entsprechend.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu diesem Produkt wende dich bitte an den Hersteller oder einen autorisierten Händler. Stelle sicher, dass du alle relevanten Informationen bereithältst, wenn du Unterstützung anforderst.

Diese Sicherheitshinweise sind wichtig für deine Sicherheit und die anderer. Bitte befolge sie sorgfältig, um ein sicheres Schießerlebnis mit der SL MEGA RIFLE REST von RANSOM zu gewährleisten.

SL MEGA RIFLE REST Safety Instruction Guide

Introduction

Thank you for choosing the SL MEGA RIFLE REST by Ransom International. This product is designed to provide stability and precision for your shooting needs. To ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read this safety instruction guide carefully before using the product.

General Safety Guidelines

- Always ensure that the SL MEGA RIFLE REST is used in accordance with local laws and regulations regarding firearms and shooting sports.
- Inspect the product before each use. Check for any signs of wear or damage that could affect safety and performance.
- Keep the product out of reach of children and unauthorized users.
- Use the product only for its intended purpose as described in this manual.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the SL MEGA RIFLE REST is placed on a stable and level surface before use to prevent tipping or sliding.
- Do not exceed the recommended weight limit of approximately 90 pounds for the basic rest.
- Always use the Elevation Block and Major Column as instructed to ensure proper adjustment and stability.
- When adjusting the Elevation Block, do so slowly and carefully to avoid sudden movements that could lead to accidents.
- If using the Windage Adjustable Bag Plate, ensure that it is securely attached and adjusted according to your shooting requirements.
- Always follow the shooting range rules and regulations when setting up and using the rifle rest.

Instructions for Installation and Usage

Installation

1. **Unboxing:** Carefully remove the SL MEGA RIFLE REST from its packaging. Ensure all components are included.
2. **Setting Up the Base:**
 - Place the Rear Plate on a stable surface.
 - Attach the Front Plate to the Rear Plate using the Bridge Plate if desired or as per shooting discipline requirements.
3. **Adjusting the Elevation:**
 - Use the 1/4" screws to attach the Elevation Block to the Front Plate.
 - Adjust the Elevation Block by turning the cast iron Elevation Wheel until the desired height is achieved.
4. **Leveling:**
 - Use the embedded level in the Elevation Block to ensure the Front Plate is level.
 - Adjust the Base Leveling Screws on both plates to achieve a level setup.

Usage

1. **Positioning:** Place your rifle on the Front Plate, ensuring it is securely supported.
2. **Alignment:** If necessary, remove the Bridge Plate to align the Front and Rear Plates for precision shooting.
3. **Windage Adjustment:** If required, adjust the Windage Adjustable Bag Plate by removing the screws and repositioning it for right or left hand windage.

4. **Shooting:** Follow all safety protocols for handling firearms while using the rifle rest.

Disposal Instructions

- Dispose of the SL MEGA RIFLE REST in accordance with local regulations regarding metal and composite materials.
- If the product is damaged beyond use, ensure that it is recycled or discarded in a manner that does not pose a risk to the environment or public safety.

Contact Information for Further Support

For safety inquiries, product support, or to report unsafe conditions, please contact Ransom International through the appropriate channels. Ensure to have your product details at hand for efficient assistance.

By following these safety instructions, you will ensure a safer experience with the SL MEGA RIFLE REST. Always prioritize safety and compliance with regulations for the best shooting experience.

Guida alle Istruzioni di Sicurezza per il SL MEGA RIFLE REST di RANSOM

Introduzione

Grazie per aver scelto il SL MEGA RIFLE REST di RANSOM. Questo prodotto è progettato per fornire stabilità e precisione durante il tiro a lunga distanza. È importante seguire attentamente le istruzioni di sicurezza per garantire un uso corretto e sicuro del prodotto.

Linee Guida Generali di Sicurezza

- Prima di utilizzare il riposo per fucile, leggere attentamente tutte le istruzioni incluse nel manuale.
- Assicurarasi che il prodotto sia assemblato correttamente prima dell'uso.
- Non utilizzare il prodotto in condizioni meteorologiche avverse o in ambienti pericolosi.
- Tenere il prodotto lontano dalla portata dei bambini e di persone non autorizzate.
- Segnalare immediatamente qualsiasi difetto o anomalia riscontrata nel prodotto.

Precauzioni di Sicurezza Specifiche per l'Uso

- Utilizzare il SL MEGA RIFLE REST solo con armi lunghe compatibili.
- Assicurarasi che il fucile sia scarico prima di posizionarlo sul riposo.
- Non posizionare mai il viso o le mani sopra l'arma mentre è montata sul riposo.
- Verificare che tutte le parti siano serrate e sicure prima di ogni utilizzo.
- Non modificare il prodotto in alcun modo. Le modifiche possono compromettere la sicurezza e l'efficacia.

Istruzioni per l'Installazione e l'Uso

1. Assemblaggio del Prodotto

- Rimuovere il prodotto dalla confezione e controllare che tutte le parti siano presenti.
- Seguire le istruzioni di assemblaggio passo dopo passo, assicurandosi che ogni componente sia montato correttamente.

2. Posizionamento del Fucile

- Posizionare la Piastra Anteriore su una superficie piana e stabile.
- Montare il fucile sulla Piastra Anteriore, assicurandosi che sia ben fissato.
- Utilizzare il Blocco di Elevazione per regolare l'altezza del fucile in base alle proprie esigenze.

3. Regolazione

- Utilizzare il livellatore integrato per assicurarsi che il fucile sia in posizione orizzontale.
- Regolare le viti di livellamento per stabilizzare ulteriormente il riposo.

4. Utilizzo

- Una volta che il fucile è montato e livellato, è possibile procedere con il tiro.
- Monitorare costantemente la stabilità del riposo durante l'uso.

Istruzioni per lo Smaltimento

- Seguire le normative locali per lo smaltimento dei materiali del prodotto.
- Non gettare il prodotto o le sue parti nell'ambiente.

- Contattare un centro di raccolta autorizzato per un corretto smaltimento.

Informazioni di Contatto per Ulteriore Supporto

Per qualsiasi domanda o problema relativo alla sicurezza del prodotto, è possibile contattare il servizio clienti di RANSOM. Assicurarsi di avere il numero di modello e la prova di acquisto a portata di mano per facilitare il supporto.

Conclusione

Il SL MEGA RIFLE REST di RANSOM è progettato per offrire prestazioni elevate e sicurezza. Seguendo queste linee guida, è possibile garantire un'esperienza di tiro sicura e soddisfacente. Ricordate di rimanere informati su eventuali aggiornamenti di sicurezza e richiami tramite il sistema di Safety Gate dell'UE.