

SEND IT-XSL PRECISION SHOOTING LEVEL - SEND IT-XSL ELECTRONIC LEVEL, BLACK

Ensures Your Optic and Rifle are Level

The Long Range Arms Send It XSL Precision Shooting Level provides all of the benefits of electronic rifle leveling for competitors and shooters, all at a price that they can afford. The Long Range Arms Send It XSL Precision Shooting Level differs from the company's top-line shooting level in that it leaves out the backup Spirit level and passing the cost savings onto the consumer. The level provides users with a green LED that indicates when the rifle is level, and the system works up to five times quicker than a comparable mechanical device. Includes automatic directional orientation Compatible with night-vision and thermal optics Provides battery-level check Toolless design allows for easy installation and removal The Long Range Arms Send It XSL Precision Shooting Level is factory-calibrated with a 12-point reference system that ensures its accuracy.



Attributes

- Name: SEND IT-XSL ELECTRONIC LEVEL, BLACK
- Manufacturer: LONG RANGE ARMS
- Product no.: 100029301
- Mfr. No.: SEND IT-XSL
- Finish: Black
- Delivery weight: 0.136kg
- Shipping height: 76mm
- Shipping width: 51mm
- Shipping length: 114mm
- UPC: 867982000325

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das Long Range Arms Send It XSL PräzisionsSchießniveau](#)
- [English: Safety Instruction Guide for the Long Range Arms Send It XSL Precision Shooting Level](#)

Sicherheitshinweise für das Long Range Arms Send It XSL PräzisionsSchießniveau

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Long Range Arms Send It XSL PräzisionsSchießniveaus! Dieses Produkt wurde entwickelt, um Ihnen eine präzise und benutzerfreundliche Lösung für die Nivellierung Ihres Gewehrs zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Überprüfen Sie regelmäßig den Zustand des Niveaus, um sicherzustellen, dass es ordnungsgemäß funktioniert.
- Lagern Sie das Produkt an einem trockenen, kühlen Ort, um Beschädigungen zu vermeiden.
- Halten Sie das Produkt von Kindern und gefährdeten Personen fern.
- Informieren Sie sich über Rückrufaktionen und Sicherheitswarnungen über die Safety GatePlattform der EU.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das Niveau ausschließlich mit kompatiblen Gewehren und Optiken.
- Achten Sie darauf, dass das Niveau korrekt kalibriert ist, bevor Sie es verwenden.
- Verwenden Sie das Niveau nicht in extremen Wetterbedingungen, die die Funktionalität beeinträchtigen könnten.
- Überprüfen Sie die Batterie regelmäßig, um sicherzustellen, dass das Niveau ordnungsgemäß funktioniert.
- Vermeiden Sie den Kontakt mit Wasser oder anderen Flüssigkeiten, um Schäden zu verhindern.

Anleitung zur Installation und Nutzung

1. Installation

- Stellen Sie sicher, dass das Gewehr sicher und stabil auf einer ebenen Fläche liegt.
- Befestigen Sie das Niveau gemäß den Anweisungen in der Bedienungsanleitung.
- Vergewissern Sie sich, dass das Niveau fest sitzt und nicht wackelt.

2. Nutzung

- Schalten Sie das Niveau ein, indem Sie den entsprechenden Knopf drücken.
- Warten Sie, bis die grüne LED leuchtet, was anzeigt, dass das Gewehr nivelliert ist.
- Überprüfen Sie regelmäßig die Anzeige, während Sie schießen, um sicherzustellen, dass das Gewehr weiterhin nivelliert ist.
- Nach der Nutzung schalten Sie das Niveau aus, um die Batterie zu schonen.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften zur Abfallentsorgung.
- Batterien sollten in speziellen Sammelstellen für Batterien entsorgt werden, um Umweltschäden zu vermeiden.
- Informieren Sie sich über die richtige Entsorgung von elektronischen Geräten in Ihrer Region.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu Ihrem Produkt wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Achten Sie darauf, alle relevanten Informationen bereit zu halten, um eine schnelle Unterstützung zu erhalten.

Vielen Dank, dass Sie sich für das Long Range Arms Send It XSL PräzisionsSchießniveau entschieden haben. Genießen Sie Ihre Schießerlebnisse und bleiben Sie sicher!

Safety Instruction Guide for the Long Range Arms Send It XSL Precision Shooting Level

Introduction

Thank you for choosing the Long Range Arms Send It XSL Precision Shooting Level. This guide provides important safety information and instructions to ensure the safe use of this product. Please read this document carefully before using the level to maximize its benefits and ensure your safety.

General Safety Guidelines

- **Product Safety:** This product is designed to be safe for use. However, improper handling or usage can lead to accidents. Always follow the instructions provided.
- **Enhanced Recalls:** In the event of a safety issue, you will be notified through standardized recall notices. Please ensure you register your product for updates.
- **Online Shopping:** If purchased online, the same safety standards apply as those in physical stores. Ensure you buy from authorized sellers.
- **Special Consumer Focus:** This product is not intended for use by children. Keep it out of reach of minors.
- **EU Contact Point:** For safety inquiries, please refer to the EU contact point listed on the product packaging.
- **Rapid Alerts:** Stay informed about safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Avoid Extreme Conditions:** Do not use the level in extreme temperatures or conditions that could affect its performance.
- **Check for Damage:** Before each use, inspect the level for any signs of damage. Do not use if damaged.
- **Battery Safety:** Ensure the battery is installed correctly. Replace with the same type of battery to avoid malfunction.
- **Avoid Water Exposure:** The level is not waterproof. Keep it dry during use.
- **Proper Handling:** Handle the level with care to avoid dropping or damaging it.

Instructions for Installation and Usage

1. Installation:

- Ensure the rifle is unloaded before attaching the level.
- Use the toolless design to easily attach the level to your rifle.
- Align the level according to the manufacturer's guidelines for optimal performance.

2. Usage:

- Turn on the level using the designated power button.
- The green LED will indicate when the rifle is level.
- For optimal results, ensure you are in a stable position while taking measurements.
- If the LED does not light up, check the battery and replace if necessary.

Disposal Instructions

- **Battery Disposal:** Dispose of batteries according to local regulations. Do not throw batteries in regular trash.
- **Product Disposal:** When the product reaches the end of its life, dispose of it in accordance with local

electronic waste regulations.

Contact Information for Further Support

For any questions or concerns regarding the Long Range Arms Send It XSL Precision Shooting Level, please refer to the contact information provided on the product packaging or visit the manufacturer's website.

Thank you for your attention to these safety guidelines. Enjoy using your Long Range Arms Send It XSL Precision Shooting Level responsibly!