

BEARING DELAY 9MM LUGER COMPLETE UPPER RECEIVER - BEARING DELAY 9MM LUGER 16" BBL ASSEMBLED UPPER RECEIVER

The Bearing Delay Upper Receiver is a complete upper receiver system ready to be paired with the AR lower receiver of your choice. Available in 5 different barrel lengths: 4.5", 7.5", 11", 14.5", 16" - all threaded for a 1/2-28 muzzle device. No 9mm-specific buffer needed. The Bearing Delay Upper Receiver is designed to work with standard AR-15 buffers. The heart of the Bearing Delay Upper Receiver is the unique ball bearing bolt carrier group (BCG). The ball bearings interface with corresponding features in the barrel extension and provide the lockup in battery and the delay after firing. The system can be tuned by replacing the Lifter to change the angle of the surfaces that push the bearings from the inside of the BCG. The bolt face includes our unique center ejector to provide the most consistent ejection of any 9mm AR on the market. The firing pin passes through the ejector. Take all the benefits of roller delay: reliability, durability, low recoil and combine with the familiarity of the AR-15 platform. Rollers are obsolete. Each of Mean's ball bearings has the same contact surface area of the original MP5 roller. So with their 3 bearings, they have 50% more contact surface area than a traditional roller delay. This means that even with the higher pressures of modern ammunition, the Bearing Delay system has greater durability than any roller delay. The ability to tune the system by swapping the Lifter means that the Bearing Delay™ system can be tuned based on ammunition type, barrel length, suppressor, or any other factor. Each Bearing Delay Upper Receiver includes two Lifters. If you elect to use MEAN Arms Endomags (Ejectorless), the Bearing Delay Upper Receiver is compatible with milspec lower receivers OR you can use dedicated pistol magazine lower receivers. Most pistol magazine lower receivers will need to have the stationary ejector removed to be compatible with the Bearing Delay system. Each Bearing Delay Upper Receiver includes 2 Ejectorless Endomags. MA Upper Receiver The Bearing Delay Upper Receiver includes a slick side billet machined aluminum upper receiver that adheres to milspec standards. No forward assist. MA Handguard The new MA Handguard is a free float hybrid design including a very rigid high temperature and high strength polymer body with a metallic insert that is overmolded (permanently attached) within the handguard and threads onto the specially designed barrel nut. Internal width (flat to flat): ~1.375" Available in 5 lengths based on the barrel configurations of the Bearing Delay Upper Receiver. MA Charging Handle The MA Charging Handle is a new ambidextrous design incorporating both steel and aluminum machined components. MA Muzzle Device The MA Muzzle Device reduces recoil and muzzle flash. Comes with a left-hand threaded jam nut which eliminates the need for a crush washer. SPECS Caliber: 9×19mm Parabellum Compatible with both milspec AR-15 and dedicated pistol-magazine lower receivers Works with standard AR-15 buffers 5 available barrel lengths: 4.5", 7.5", 11", 14.5" and 16" Weight of entire Upper (BCG alone is just under 11oz) 4.5" is 2.59 lbs 7.5" is 2.92 lbs 11" is 3.23 lbs 14.5" is 3.57 lbs 16" is 3.72 lbs Each Bearing Delay Upper Receiver includes: Fully tunable ball bearing bolt carrier group MA Upper Receiver - slick side billet machined aluminum upper receiver MA Handguard - free float hybrid metal/polymer design MA Charging Handle - new ambidextrous design MA Muzzle Device - exclusive machined design reduces recoil and muzzle flash Also included with the purchase of the Bearing Delay Upper Receiver: 1 additional Lifter for tuning the system (2 total included) 2 Ejectorless EndoMags (PMAGs NOT included)



Attributes

- Name: BEARING DELAY 9MM LUGER 16" BBL ASSEMBLED UPPER RECEIVER
- Manufacturer: MEAN ARMS
- Product no.: 430109851
- Mfr. No.: 2102069
- Cartridge: 9 mm Luger
- Color: Black
- Finish: Matte
- Length: 16"
- Make: AR-15
- Muzzle: 1/2-28
- Style: Complete
- Delivery weight: 2.268kg
- UPC: 855926007189

Item details

Made in USA

This product is excluded from discount promotions.

US export classification: I(g)

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den BEARING DELAY 9MM LUGER COMPLETE UPPER RECEIVER](#)
- [English: Safety Instruction Guide for Bearing Delay 9mm Luger Complete Upper Receiver](#)
- [Norsk: Bruksanvisning for Bearing Delay 9mm Luger Complete Upper Receiver](#)

Sicherheitshinweise für den BEARING DELAY 9MM LUGER COMPLETE UPPER RECEIVER

Einführung

Vielen Dank, dass Sie sich für den BEARING DELAY 9MM LUGER COMPLETE UPPER RECEIVER entschieden haben. Dieser Leitfaden bietet wichtige Informationen zur sicheren Nutzung, Installation und Entsorgung des Produkts. Bitte lesen Sie alle Anweisungen sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie alle Anweisungen und Warnungen in diesem Handbuch befolgen.
- Verwenden Sie das Produkt nur gemäß den vorgesehenen Spezifikationen.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und anderen gefährdeten Gruppen.
- Überprüfen Sie das Produkt regelmäßig auf Anzeichen von Beschädigungen oder Abnutzung.
- Melden Sie unsichere Produkte und Unfälle an die zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die empfohlenen Munitionsarten mit dem Upper Receiver.
- Achten Sie darauf, dass der Upper Receiver korrekt auf dem ARLowerReceiver montiert ist.
- Überprüfen Sie vor jeder Verwendung, ob der Verschluss in der Batteriestellung ist.
- Verwenden Sie beim Umgang mit dem Produkt immer geeignete Schutzausrüstung, wie z.B. Schutzbrille und Gehörschutz.
- Führen Sie keine Modifikationen am Produkt durch, die nicht ausdrücklich in der Anleitung erwähnt werden.
- Lagern Sie das Produkt an einem trockenen, sicheren Ort.

Anweisungen zur Installation und Nutzung

1. Installation des Upper Receivers:

- Stellen Sie sicher, dass der ARLowerReceiver sauber und frei von Schmutz ist.
- Richten Sie den Upper Receiver mit dem Lower Receiver aus und drücken Sie ihn vorsichtig in die richtige Position.
- Überprüfen Sie, ob alle Pins und Riegel korrekt eingerastet sind.

2. Nutzung des Upper Receivers:

- Laden Sie die Waffe gemäß den Anweisungen des Herstellers.
- Überprüfen Sie vor dem Schuss, ob alle Sicherheitsvorkehrungen getroffen wurden.
- Nach dem Schießen, reinigen Sie den Upper Receiver gründlich, um Rückstände zu entfernen.

3. Feinabstimmung des Systems:

- Verwenden Sie die mitgelieferten Lifter, um das System an verschiedene Munitionsarten und Lauflängen anzupassen.
- Testen Sie die Funktionalität nach jeder Anpassung, um sicherzustellen, dass alles ordnungsgemäß funktioniert.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass alle Teile des Produkts vollständig entleert und gereinigt sind, bevor Sie es entsorgen.
- Informieren Sie sich über lokale Recyclingmöglichkeiten für Metall und Kunststoff.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu diesem Produkt stehen Ihnen verschiedene Ressourcen zur Verfügung. Bitte kontaktieren Sie den Hersteller oder besuchen Sie die offizielle Website für Unterstützung.

Bitte beachten Sie, dass diese Sicherheitsanweisungen gemäß der EUVerordnung über die allgemeine Produktsicherheit (GPSR) erstellt wurden. Es ist wichtig, dass Sie alle Informationen sorgfältig befolgen, um Ihre Sicherheit und die Sicherheit anderer zu gewährleisten.

Safety Instruction Guide for Bearing Delay 9mm Luger Complete Upper Receiver

Introduction

Thank you for choosing the Bearing Delay 9mm Luger Complete Upper Receiver. This product is designed to provide a reliable and durable shooting experience. However, it is essential to follow safety guidelines to ensure safe usage and to minimize risks. This guide outlines important safety information, installation instructions, and contact information for further support.

General Safety Guidelines

- Always treat the upper receiver as if it is loaded, even when it is not.
- Keep the upper receiver out of reach of children and unauthorized users.
- Use only compatible ammunition as specified in the product specifications.
- Regularly inspect the upper receiver for any signs of wear or damage before use.
- Ensure that the firearm is in good working condition and compliant with local laws.
- Follow all local, state, and national laws regarding firearm ownership and usage.
- Do not modify the upper receiver or any components without consulting a qualified gunsmith.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and hearing protection, when using the firearm.

Specific Safety Precautions for Use

- Ensure that the Bearing Delay Upper Receiver is properly mounted to a compatible AR lower receiver before use.
- Verify that the muzzle device is securely attached and correctly installed.
- Do not attempt to use the upper receiver with any ammunition that exceeds the specified caliber (9×19mm Parabellum).
- Be aware of the potential for recoil and ensure that you are in a stable shooting position.
- Avoid using the upper receiver in adverse weather conditions that may affect performance or safety.
- If using with MEAN Arms Endomags, ensure compatibility with your lower receiver and remove the stationary ejector if necessary.
- If you experience any malfunctions or irregularities during operation, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation of the Upper Receiver:

- Ensure that the AR lower receiver is clean and free of obstructions.
- Align the Bearing Delay Upper Receiver with the lower receiver.
- Secure the upper receiver to the lower receiver using the takedown pins.
- Confirm that the upper receiver is properly locked in place.

2. Installation of the Handguard:

- Thread the MA Handguard onto the specially designed barrel nut.
- Ensure that the handguard is securely attached and does not move when pulled.

3. Charging Handle Usage:

- Pull the MA Charging Handle to the rear to chamber a round.

- Release the charging handle to allow it to return to its forward position.

4. Muzzle Device Usage:

- Ensure that the MA Muzzle Device is properly installed and tightened.
- Check for any signs of damage or wear before each use.

5. Ejection of Casings:

- After firing, observe the ejection pattern to ensure proper functioning.
- If casings do not eject properly, cease use and inspect the system for issues.

Disposal Instructions

- Dispose of the upper receiver and any associated components in accordance with local regulations.
- Do not dispose of the upper receiver in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Bearing Delay Upper Receiver, please consult the product manual or contact your retailer for assistance. It is important to ensure that you are receiving accurate and reliable information regarding the product's use and safety.

Thank you for your attention to these safety guidelines. Your safety and the safety of those around you are our top priority. Always practice safe handling and storage of your firearm and its components.

Bruksanvisning for Bearing Delay 9mm Luger Complete Upper Receiver

Introduksjon

Takk for at du valgte Bearing Delay 9mm Luger Complete Upper Receiver fra Mean Arms. Denne guiden inneholder viktige sikkerhetsinstruksjoner og retningslinjer for bruk av produktet. Vennligst les nøye gjennom all informasjon før bruk for å sikre trygg og effektiv drift.

Generelle sikkerhetsretningslinjer

- Sørg for at produktet er i god stand før bruk.
- Bruk alltid personlig verneutstyr, inkludert ørebeskyttelse og vernebriller, ved skyting.
- Oppbevar produktet utilgjengelig for barn og uautoriserte personer.
- Les og forstå alle instruksjoner og advarsler før montering og bruk.
- Følg lokale lover og forskrifter vedrørende bruk av skytevåpen og tilbehør.

Spesifikke sikkerhetstiltak for bruk

- Unngå å bruke produktet med defekte eller skadde deler.
- Kontroller at alle deler er riktig montert før bruk.
- Hold våpenet rettet bort fra deg og andre når du håndterer det.
- Sørg for at våpenet er tomt før du monterer eller demonterer Upper Receiver.
- Unngå å bruke ammunisjon som ikke er spesifisert for produktet.

Instruksjoner for installasjon og bruk

1. Montering av Upper Receiver:

- Sørg for at ARlower receiver er kompatibel med Bearing Delay Upper Receiver.
- Plasser Upper Receiver på ARlower receiver og fest den med de medfølgende skruene.
- Kontroller at alt sitter godt og er sikkert festet.

2. Justering av systemet:

- Bytt ut Lifter for å justere vinkelen på overflatene som presser lagrene fra innsiden av BCG.
- Sørg for at justeringen er i samsvar med ammunisjonstypen og løpet lengde.

3. Bruk av Endomags:

- Installer Endomags i henhold til produsentens instruksjoner.
- Kontroller at magasinet er sikkert festet før bruk.

4. Rengjøring og vedlikehold:

- Rengjør Upper Receiver regelmessig for å fjerne smuss og avleiringer.
- Inspiser alle deler for slitasje og bytt ut skadete komponenter umiddelbart.

Avfallsinstruksjoner

- Følg lokale forskrifter for avhending av skytevåpen og tilbehør.
- Lever skadde eller uønskede deler til godkjente avfallsmottakere.
- Unngå å kaste deler i vanlig husholdningsavfall.

Kontaktinformasjon for videre støtte

For ytterligere støtte og informasjon om produktet, vennligst kontakt produsenten eller din lokale forhandler. Sørg for å ha produktets serienummer tilgjengelig for raskere assistanse.

Vennligst vær oppmerksom på at det er ditt ansvar å bruke produktet på en trygg og ansvarlig måte. Ved å følge disse retningslinjene kan du bidra til å sikre en trygg opplevelse med Bearing Delay 9mm Luger Complete Upper Receiver.