

AR-15 ULTRAMATCH - CAL. 223 REM.

The Schmeisser AR15 Ultramatch is a precision rifle with a match barrel and an integrated spare magazine in the stock. This rifle has a .936 free-swinging match barrel, a slim M-Lok handguard and a adjustable gas block made of steel. The Two-Stage trigger guarantees a clearly defined dry trigger. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. Standard delivery with a 10 round magazine.

- NAME: AR15 Ultramatch 20" STS
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 4.000 g
- LENGTH: 97 cm (Fixedstock)
- BARREL: 51 cm
- TWIST: 1:8
- MAGAZINE: 10 rds

NO IMAGE
AVAILABLE

Attributes

- Name: SCHMEISSER AR-15 ULTRAMATCH - CAL. 223 REM.
- Manufacturer: SCHMEISSER
- Product no.: EU2004558
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 20"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Black
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-8
- EAN: 4251366502141

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem.](#)
- [English: Safety Instruction Guide for SCHMEISSER AR15 ULTRAMATCH CAL. 223 REM.](#)

Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem.

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Schmeisser AR15 Ultramatch. Diese Präzisionswaffe wurde mit höchsten Standards entwickelt, um Ihnen eine sichere und zuverlässige Nutzung zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie die Waffe sicher und verantwortungsvoll verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Halten Sie die Waffe immer in einem sicheren Zustand, wenn sie nicht in Gebrauch ist.
- Behandeln Sie jede Waffe, als ob sie geladen wäre.
- Zeigen Sie die Mündung der Waffe niemals auf etwas, das Sie nicht treffen möchten.
- Halten Sie den Abzug nicht gedrückt, während Sie die Waffe laden oder entladen.
- Verwahren Sie die Waffe an einem sicheren Ort, der für unbefugte Personen, insbesondere Kinder, unzugänglich ist.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Überprüfen Sie vor jedem Gebrauch, ob die Waffe sauber und funktionsfähig ist.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie schießen.
- Tragen Sie immer geeignete Augen und Gehörschutzvorrichtungen während des Schießens.
- Üben Sie Schießen nur auf dafür vorgesehenen und sicheren Schießständen.

Anleitung zur Installation und Nutzung

• Installation des Zubehörs:

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie Zubehör installieren.
- Befestigen Sie den MLok Vorderschaft gemäß den Anweisungen des Herstellers.
- Überprüfen Sie alle Verbindungen auf Festigkeit und Sicherheit.

• Nutzung der Waffe:

- Laden Sie die Waffe, indem Sie das Magazin korrekt einsetzen und den Durchladehebel betätigen.
- Stellen Sie sicher, dass der TwoStage Trigger richtig eingestellt ist, um einen klaren Schuss zu gewährleisten.
- Verwenden Sie die Sicherung, wenn die Waffe nicht in Gebrauch ist.

• Wartung:

- Reinigen Sie die Waffe regelmäßig, um ihre Funktionsfähigkeit zu gewährleisten.
- Überprüfen Sie alle Teile auf Abnutzung und ersetzen Sie defekte Teile sofort.
- Lagern Sie die Waffe an einem trockenen und sicheren Ort.

Entsorgungsanweisungen

- Entsorgen Sie alle leeren Patronen und Munition gemäß den örtlichen Vorschriften.
- Wenn Sie die Waffe nicht mehr benötigen, wenden Sie sich an autorisierte Stellen für die sichere

Entsorgung.

- Halten Sie sich an die gesetzlichen Bestimmungen zur Entsorgung von Feuerwaffen in Ihrem Land.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Anliegen bezüglich der Sicherheit oder Nutzung Ihrer Schmeisser AR15 Ultramatch, wenden Sie sich bitte an den Hersteller oder autorisierte Fachhändler.

Schlussfolgerung

Die Schmeisser AR15 Ultramatch ist eine hochentwickelte Waffe, die verantwortungsvolle Nutzung erfordert. Indem Sie diese Sicherheitshinweise befolgen, tragen Sie zu Ihrer eigenen Sicherheit und der Sicherheit anderer bei. Bleiben Sie informiert und handeln Sie stets verantwortungsbewusst.

Safety Instruction Guide for SCHMEISSER AR15 ULTRAMATCH CAL. 223 REM.

Introduction

Thank you for choosing the SCHMEISSER AR15 Ultramatch. This precision rifle is designed for safety and performance. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your rifle. Please read this document carefully before using the product.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the SCHMEISSER AR15 Ultramatch by following all safety instructions. This product complies with EU General Product Safety Regulation (GPSR).
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to your rifle. You can check for updates on the EU Safety Gate platform.
- **Online Shopping Protections:** If purchased online, ensure that the retailer meets safety requirements similar to physical stores.
- **Vulnerable Groups:** Extra caution should be taken if the rifle is accessible to vulnerable individuals, including children.
- **EU Contact Point:** For any safety inquiries, refer to the EU-based contact information provided by the manufacturer or retailer.
- **Rapid Alerts:** Be aware of rapid alerts regarding unsafe products through the Safety Gate system.

Specific Safety Precautions for Use

- **Always treat the rifle as if it is loaded:** Never assume a firearm is unloaded. Always check the chamber and magazine.
- **Keep the muzzle pointed in a safe direction:** Always ensure the rifle is pointed away from yourself and others.
- **Store the rifle safely:** When not in use, store the rifle in a secure location, preferably locked, and out of reach of children and unauthorized users.
- **Use appropriate ammunition:** Only use .223 Remington ammunition as specified for this rifle.
- **Wear eye and ear protection:** Always use protective gear when shooting to prevent injury from noise and debris.
- **Be aware of your surroundings:** Always be conscious of what is beyond your target and ensure a safe shooting environment.
- **Do not modify the rifle:** Making unauthorized modifications can compromise safety and performance.

Instructions for Installation and Usage

Installation

- **Attach the Handguard:** Ensure the MLoc handguard is securely attached to the rifle. Follow the manufacturer's instructions for proper installation.
- **Install the Adjustable Gas Block:** Ensure the gas block is correctly adjusted for optimal performance. Refer to the specific installation manual if available.

Usage

- **Loading the Magazine:**
 - Ensure the rifle is pointed in a safe direction.
 - Insert the magazine into the magazine well until it clicks into place.

- Check that the magazine is securely locked in.
- **Firing the Rifle:**
 - Ensure the safety selector is in the "fire" position.
 - Take a stable shooting stance and ensure your grip is firm.
 - Aim at your target and squeeze the trigger gently to fire.
- **Unloading the Rifle:**
 - Point the rifle in a safe direction.
 - Remove the magazine from the rifle.
 - Open the action and visually and physically check the chamber to ensure it is clear.

Disposal Instructions

- **Dispose of Unused Ammunition:** Follow local regulations for the disposal of unused or expired ammunition.
- **Disposal of the Rifle:** If you need to dispose of the rifle, contact a local firearms dealer or authority for proper disposal methods in compliance with local laws.

Contact Information for Further Support

For any inquiries regarding safety, usage, or support related to your SCHMEISSER AR15 Ultramatch, please refer to the contact information provided by your retailer or the manufacturer.

By following these safety guidelines and instructions, you can help ensure a safe and enjoyable experience with your SCHMEISSER AR15 Ultramatch rifle. Always prioritize safety and responsibility when handling firearms.