

Seater Spindle - Spindle seater M6/M4 L=65mm

Spindle for seating dies, precision-made from steel and blued – high-quality replacement part for fast and precise adjustment of seating depth. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Spindle seater M6/M4 L=65mm
- Manufacturer: TRIEBEL
- Product no.: EU2017371
- Mfr. No.: 3000053V-65
- Length: 65
- Thread: M6 / M4
- Delivery weight: 0.015kg
- Shipping height: 65mm
- Shipping width: 6mm
- Shipping length: 6mm
- EAN/UPC: 3000053V-65

Table of Contents

- [Startpage](#)
- [English: Seater Spindle Safety Instruction Guide](#)

Seater Spindle Safety Instruction Guide

Introduction

Thank you for choosing the Seater Spindle M6/M4 L=65mm. This precisionmade spindle is designed for seating dies and is made from highquality steel. It is essential to follow safety guidelines to ensure safe and effective use of this product. This guide provides important safety information, usage instructions, and disposal guidelines in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified in this guide.
- Always inspect the spindle for any signs of damage or wear before use.
- Keep the spindle out of reach of children and vulnerable individuals.
- Use the spindle in a welllit and safe working environment.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the spindle.
- Avoid using the spindle if you are under the influence of alcohol or drugs.
- Ensure that the spindle is securely attached to the tool before use to prevent accidents.
- Do not exceed the recommended specifications for the spindle, including the thread sizes (M6/M4) and length (65mm).
- Do not use the spindle for any purpose other than seating dies as intended.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials before starting the installation process.
- Ensure that the work area is clean and free from any hazards.

2. Installation

- Carefully read the instructions provided with your die set.
- Align the spindle with the die and ensure that the threads (M6/M4) match correctly.
- Gently screw the spindle into place, taking care not to crossthead.
- Tighten securely, but do not overtighten, as this may damage the spindle or die.

3. Usage

- Once installed, adjust the spindle to the desired seating depth as specified in your die instructions.
- Make small adjustments and check the seating depth frequently to ensure accuracy.
- If any resistance is felt during adjustment, stop immediately and check for obstructions or misalignment.

4. PostUsage

- After use, carefully remove the spindle from the die.
- Clean the spindle with a dry cloth to remove any debris or residue.
- Store the spindle in a safe and dry location to prevent damage.

Disposal Instructions

- Dispose of the spindle in accordance with local regulations regarding metal waste.
- Do not dispose of the spindle in regular household waste.
- If the spindle is damaged beyond repair, ensure it is recycled or disposed of properly to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the Seater Spindle, please refer to the product packaging for contact details of the manufacturer or the authorized distributor. They will provide the necessary assistance and support regarding safety inquiries and product usage.

Thank you for prioritizing safety and for your trust in our product. Enjoy your experience with the Seater Spindle, and always follow these guidelines to ensure safe and effective use.